

**Cowan School Corporation**  
**Wastewater Treatment Plant/Lagoon Closure**  
**Specifications**

- Remove all piping and equipment from top of tankage
- Cut a 2" drain hole in each compartment of all tankage at the bottom of the tanks
- Remove Ultra Violet disinfection equipment, flow meter, and electrical (turn over to owner)
- Fill tanks and lagoon with fill sand within eight inches from the top of the tanks
- Install six inches of #2 stone
- Install two inches of #53 stone
- Install additional two inches to the graveled area (to be used as additional parking area)
- Remove electrical breaker panel and disconnect in the school maintenance room
- Remove water hydrant and reconnect water to feed the bus barn (Use like material when connection is made)
- Remove 600' of fence and fence posts. Fill holes with fill sand, #2 stone and #53 stone as the tanks/lagoon
- Demolish block wall of the lagoon.(Blocks can be used as fill after blocks are broken up)
- Approximant size of the lagoon is 60'x60'x5'
- Contractor shall follow all federal, state and local laws
- General site clean up of clay pipe, pumps, blower covers (Site shall look like a parking area free of debris when complete)
- All work shall be digitally documented (email to [erin@sweetenterprises.net](mailto:erin@sweetenterprises.net))
- Certificate of insurance must be provided before any work is to start